


6" Touchscreen Camera Monitor

USB2.0 Recording | HDMI with LUT Loop-out



User Manual

Foreword

Thank you for purchasing our 6-inch Full HD touch screen monitor. Please read this manual carefully before using the unit. Have a great experience!

CAUTION

1. Please avoid the heavy impact and drop onto the ground when move the product.
2. The screen of this product is made of glass. Keep away from injury if the screen is broken.
3. Keep the product away from the heat source, and avoid the prolonged exposures to the sun as the LCD screen will be damaged.
4. Please do NOT use chemical solutions to clean this product. Please wipe the monitor with a clean soft cloth to maintain the brightness of the surface.
5. No adjustable components are in the monitor. Please do not take apart or repair the unit by yourself, to avoid the damage of the product.

Key Features

- 6-inch 1920x1080 full HD IPS screen
- Touch screen menu operation, improve shooting efficiency
- New menu interface, more intuitive and intelligent
- HDMI 2.0 input supports up to 4K@60Hz, 3G-SDI (optional)
- HDMI supports LUT loop-out
- Support HDR monitoring, what you see is what you get
- Support 3D LUT Log to REC.709 and user 3D LUT upload


- With Waveform, Histogram, False Color, Monochrome etc. functions, can help you accurately exposure and focus every shot.
- Stereo Earphone output
- DC 8.4V power out to power your DSLR camera or mirrorless camera
- Built-in cooler (low, medium, high) to adjust
- Flexible power supply (DC IN 12V, F970 battery plate for F970 batteries)

CONTENTS

1. Product Description -----	4
1.1 Front + Rear -----	4
1.2 Button / Interface Instruction -----	4
1.3 Power Supply Way -----	6
1.4 Mount Points -----	7
2. Menu Operation Instruction -----	8
2.1 Touch Screen Menu Operation -----	8
2.2 MENU Wheel Menu Operation -----	9
3. Function Instruction -----	9
3.1 Menu Function -----	9
3.2 Shortcut Menu -----	16
3.3 Status column -----	16
4. How to Load LUT -----	18
5. Support Formats -----	19
6. Technical Parameters -----	19
7. Trouble Shooting -----	20


1. Product Description

1.1 Front + Rear




1.2 Button / Interface Instruction

● Top




①	Power/Touch Function Button	Long press to turn on/off power; short press to turn on/off the screen touch function
②	1/4 Screw Thread	Use for mount on the bracket, etc.
③	Micro SD Card Slot	Use for upgrade/ LUT files import
④	MENU Wheel Button	See details 2.2 MENU Wheel Menu Operation in 2. Menu Operation Instruction.

● Bottom




①	Audio Output Interface	3.5mm Analog audio
②	Power Input Interface	DC 12V/1.5A
③	Power Output Interface	DC 8.4V/2A
④	1/4 Screw Thread	Use for mount on the bracket, etc.
⑤	SDI Signal Input Interface	Optional
⑥	SDI Signal Output Interface	Optional

● Left



①	HDMI Signal Output Interface	HDMI 1.4
②	HDMI Signal Input Interface	HDMI 2.0

● Right



①	USB2.0 Interface	Recording
②	1/4 Screw Thread	Use for mount on the bracket, etc.

1.3 Power Supply Way

(1) The rear cover of the monitor is equipped with F970 battery plate, which is applicable to F970 series of batteries.

Sony F970 battery plate for battery of Sony DV:

Sony F970 F960 F950 F930 F770 F750 F730 F570 F550 F530 series

Remark: It is recommended to use standard original F970 batteries. Different specifications of the battery have different capability. The working time for the monitor will be different. Higher capability (working time) will be longer. Please take off the battery from the monitor if you don't use the monitor in a long time.


(2) **DC IN 12V:** DC power input, polarity as the input power  , Barrel (5.5mm outer, 2.1mm inner) at the bottom of the monitor, DC 7~14V Input.

(3) **DC OUT 8.4V:** DC power output interface, polarity as the output power 

Barrel output for powering your camera with a separately available DC coupler via adaptor (NP-FW50 Sony & LP-E6 Canon&DMW-BLF19 Panasonic). More adapters coming soon.

1.4 Mount Points

There are (3) $\frac{1}{4}$ -20 thread points (top, bottom, right) can be easily connected to the hot shoe mount, tripod fixed installation.



2. Menu Operation Instruction


After the monitor is properly connected to the power supply, the  button display(red indicating). Long press  button to turn on the monitor and turns green indicating.

After startup, short press  button to select to turn the screen touch function on or off.

2.1 Touch Screen Menu Operation (turn on the screen touch function)

- ①. Double-click on the screen to open the main menu (show on the left side of the screen) and click on the corresponding menu to display the secondary menu. You can enter the corresponding function option and click directly to select or set. Click the touch screen to exit the menu.
- ②. When the menu is not displayed, swipe up from the bottom of the screen to open the shortcut menu, and click on the corresponding menu box to open or set the corresponding function.
- ③. When the menu is not displayed, on the left side of the screen (1/2 split screen), you can directly adjust the brightness of the screen backlight; on the right side of the screen (1/2 split screen), you can directly adjust the volume.

Figure:



2.2 MENU Wheel Menu Operation

- ①. When the menu is not displayed, directly rotate the wheel to backlight or volume adjustment. The wheel option can be set to backlight or volume in the menu  System.
- ②. Short press the MENU wheel to open the main menu (on the left side of the screen). Rotate the wheel to select the secondary function menu. After selecting it, press the wheel, then rotate the wheel to select or set the option function.
- ③. Long press the MENU wheel to open the shortcut menu (below the screen), rotate the wheel to select the shortcut menu option, press the wheel to directly turn on/off the function, if you press the parameter selection, repeat the above operation. Long press the wheel to exit.

3. Function Instruction

3.1 Menu Function

The main menu including Assist, Marker, Image, User, System 5 parts.



Assist

 Analysis	Off, On After turning on, waveform, , histogram and audio meters will be shown.
 Waveform	Off, On Type: RGB, YUV This essential feature assists with the calibration of professional video cameras. It shows the overall brightness of the image assisting the video professional in correcting exposure. The waveform feature also checks the evenness of the lighting when lighting a chromakey or background.
 Vectorscope	Off, On Shows how saturated the image is and where the pixels in the image land on the color spectrum.
 Histogram	Off, On Type: Y, RGB, Y+RGB RGB Histogram:It can display the graphic of color tone

	<p>distribution, can intuitively display the exposure status of the image, and display overlapping histograms in red, green, and blue channels</p> <p>Y Histogram: A quantitative tool to check the picture brightness, display different color for different brightness.</p>
 Focus Assist	<p>Off, On</p> <p>Focus Color: Red, Green, Blue, White</p> <p>Focus Level: 1~100</p> <p>It highlights the areas that are in focus so you are able to quickly focus the camera and not miss crucial shots.</p>
 Audio Meters	<p>Off, On</p> <p>The Audio Level Meters provide numerical indicators and headroom levels.</p>
 Check Field	<p>Off, On</p> <p>Type: red, green, blue, white</p> <p>When enabled, hue and saturation adjusted quickly and accurately</p>
 Zebra	<p>Off, On</p> <p>Level: 1~100</p> <p>Areas of the image over a certain threshold are filled with a striped pattern to dramatically highlight areas where too much light is falling on the image sensor.</p>
 False Color	<p>Off, On</p> <p>Type: Spectrum, ARRI</p> <p>An image that depicts an object in colors that differ from those a photograph (a true color image) would show.</p>



Marker

 Nine Grid	Off, On
--	----------------

	The area of the picture can be divided into nine equal grids.
 Safe Areas	Off, On Type: 70%, 80%, 90%, 16:9, 16:10, 4:3, 5:4, 1:1, 1.91:1, 4:5, 9:16: 1.85:1, 2.35:1 Line Color: Red, Green, Blue, White, Black, Yellow
 Crosshair	Off, On
 Cinema Guides	Off, On Type: 16:9, 16:10, 4:3, 1.85:1, 2.35:1, 2.41:1, 1.91:1, 5:4, 1:1.91 Line Color: Red, Green, Blue, White, Black, Yellow After the Marker Mat is turned on, the Marker Mat Alpha 0%~75% can be adjusted.



Image

 Scan Mode	Off, On Mode: Under Scan, Over Scan
 Aspect Ratio	Off, On Type: 16:9, 16:10, 4:3, 5:4, 1.85:1, 2.35:1, 2.41:1, 1.91:1, user Under the “user”, you can customize the Video Width (100% ~ 200%) , Video Height (100% ~ 200%) Provides a wide variety of aspect ratio to match different camera anamorphic lenses.
 Anamorphic	Off, On Type: 1.25x, 1.33x, 1.5x, 1.8x, 2.0x, 2.0x mag Allows you to use anamorphic lenses or adapters and see the image unsqueezed, even if your camera does not de-squeeze in camera.

	Mirror	Off, On Auto (the image will automatically adjust), 180° , H Flip , V Flip .
	Zoom	Off, On Zoom Times: 1.0x~5.0x It is HD signal in any part, an amplification for high quality close-up.
	Freeze	Off, On
	Pixel to Pixel	Off, On



User

	HDR	Off, On HLG2020、HLG709、HLG P3 HDR can provide more dynamic range and the details of image, it is better to reflect the visual effects in the real environment.
	LUT	Off, On LUT is a table for quickly looking up and output specific color data. By loading different 3D-LUT tables, it can quickly recombine color tone to form different color styles. After copying the 3D LUT file to the micro SD card and inserting it into the micro SD card slot, click Import or rotate the wheel to import the 3D LUT file. (up to 50) Note: the chip should be faced up when inserting the SD card, and press it after inserting to ensure that the SD card is fully inserted. LUT List: display built in SLOG2, SLOG3, LOGC, VLOG

	and the custom LUTs
 Display	<p>Reset: Off, On</p> <p>After reset turning on, the values of display will restore the factory.</p> <p>Color Temp.: 5600K, 6500K, 9300K, User</p> <p>Under the User, the red, green and blue of the image can be adjusted (0~255), made the colors of the image achieve your favorite.</p> <p>Backlight: 0~100</p> <p>Adjust the screen brightness</p> <p>Brightness: 0~100</p> <p>Adjust the image brightness</p> <p>Contrast: 0~100</p> <p>Adjustment of the ratio between the brightest and darkest parts of the image . When adjusting, pay attention to the sense of hierarchy in the image. If the proportion is too large or too small, it can cause the image to lose its colorful appearance.</p> <p>Saturation: 0~100</p> <p>Under the “user”, the red, green, and blue values of the image can be adjusted (0~255)</p>
Record	<p>Disk Total Size</p> <p>Disk Free Size</p> <p>Record Version</p> <p>Update</p> <p>Steps of record update: Insert the USB flash driver into the USB2.0 port of the monitor, then enter the monitor menu and click on User-- Record--Update to upgrade</p>



System


Wheel	Backlight, Volume After selecting the wheel option, you can click Backlight or Voice , or rotate the wheel to select one of the shortcut key to set it to the rotary wheel adjustment (when the menu is not displayed).
Input	HDMI, SDI (with SDI interface version)
Output	HDMI: 1080P, Follow In Mode: DVI, HDMI Bit Depth: 8bits, 10bits (output to other device can be select the bit depth)
Fan	Off, Low, Medium, High
Language	English, 中文, Español, Français, Deutsch, 日本語, 한국어로, Русский
OSD Option	OSD Time: always, 15s, 30s, 45s, 60s Select the display time of the menu on the screen OSD Alpha: 0%~75% Adjust the transparency of the menu picture background on the screen
Volume	Mute: Off, On Volume: 0~100 Adjusting the speaker volume
Reset	Off, On After confirmed, all the parameters will restore factory
Firmware Update	Firmware Version: show the current version of device Update After copying the update file to the SD card and inserting it into the micro SD card slot, you can click Update or rotate the wheel to update. Note: the chip should be faced up when inserting the SD

card, and press it after inserting to ensure that the SD card is fully inserted.

3.2 Shortcut Menu


The user can call up the shortcut menu by swipe up from the bottom of the screen, and click on the corresponding menu box to open or set the corresponding function.

Click  the hide icon to close detailed parameters, and click  icon to display detailed parameters.



3.3 Status column

The top of the interface is the status column, the user can check the input and output resolution, battery level, etc.



INPUT: display the resolution of INPUT resolution, e.g.: INPUT HDMI
1920x1080x60

OUTPUT: display the resolution of OUTPUT resolution, e.g.: OUTPUT HDMI
1920x1080x60

LUT: LUT status, when use LUT it will display the LUT name, such as SLOG2;
without LUT, display LUT monitoring, e.g.: LUT Monitor

 : Recording Key

The record function supports record 1080p30 video.

Steps of recording

1. Format USB flash driver to FAT32
2. Plug USB flash driver into USB2.0 port , the top of screen will show the red recording key, just click it to start record, and will display the recording time, when the recording is about 1 minute, the information displayed on the top screen will be hidden automatically. You can click anywhere on the screen to view the recording time.
3. Click the recording key again to end the record. Recording time depends on the capacity of external storage media, for example 1-hour live broadcast recording takes up about 1860M of memory.

Volume: display the voice 0~100

Lock: display the status of touch function. Lock indicates the touch function locked, Unlock indicates support touch.

Battery Level: battery level status, when use battery power supply, according to four full bars to display the battery level. full-bar: 80%~100%; three-bar: 50%~80%; two-bar: 30%~50%; one-bar: 10%~30%; empty: less than 10%, the color of battery icon change to red.

Note: The status bar is put away by default and is only displayed when the main menu or shortcut menu is turning on

4. How to Load LUT

4.1 micro SD card format

Support FAT32

4.2 Max Files Limit Maximum 50 Lut files

4.3 File requirements

- The LUT file format suffix should be **.cube**
- Single file not exceeded to 7.9Mb
- Support LUT-3D-Size 16,17,32,33,64,65

Remark: LUT file name must be English or Arabic numerals

4.4 Steps for loading

4.4.1 Make sure the micro SD card correctly insert

4.4.2 Enter main menu --LUT-- Import to load

the monitor will auto detect the SD card

If there is valid lut file in sd card, the monitor will load lut files and show “[n]” name. The [n] shows the quantity number. The “name” should in lut files’ name.

If load successful, the screen will show “complete[n]”. [n] Stands for the quantity number for lut files should under 50.

PS: How to clear up the imported LUTs?

Insert a empty SD card to the monitor, enter main menu --LUT-- Import the imported LUTs will be clear up.

5. Support Formats

SDI Support Format (SDI version)	480i 576i 1080i@59.94/60 720p@50/59.94/60 1080p@23.98/24/25/29.97/30/50/59.94/60 1080psf@23.8/24/25/29.7/30
HDMI 2.0 Support Format	SMpte 720p@50/60 1080i@50/60 1080p@24/30/50/60 720p (60/59.94/50/30/29.97/25/24/23.98) VESA 1024×768@60 1280×720@60 1280×768@60 1280×800@60 1280×1024@60 1360×768@60 1366×768@60 1440×900@60 1600×1200@60 1680×1050@60 1920×1080@60 1920×1200@60 3840×2160@60 4096×2160@60
HDMI 1.4 Support Format	SMpte 720p@50/60 1080p@24/25/30/50/60 VESA 1024×768@60 1280×720@50/60 1280×768@60 1280×1024@60 1360×768@60 1920×1080@24/25/30/50/60

6. Technical Parameters

Panel Size	6" touch screen
Resolution	1920 × 1080 pixels
Dot Pitch	0.069 (H) × 0.069 (V) (mm)
Aspect Ratio	16:9
Brightness	450cd/m ²
Contrast	1000:1
Viewing Angle	80°/80°(L/R) 80°/80°(U/D)
Backlight	LED
Input	SDI (optional), HDMI 2.0
Output	SDI (optional), HDMI 1.4, DC OUT 8.4V

Other Interface	USB2.0 (recording), Micro SD Card Slot
Record Format	MP4 (1080p30)
Audio	3.5mm Stereo Headphone
Power Input Voltage	7~14V
Power Consumption	≤11W
Unit Size	152Lx86Hx23D (mm)
Unit Weight	230g
Mount Points	(3) 1/4-20 thread points (top, bottom, right)
Working Temperature	-20°C~50°C
Storage Temperature	-30°C~60°C

7. Trouble Shooting

7.1 Only black and white or monochrome picture:

- ① please check saturation, brightness & contrast adjustment.
- ② Please check "Monochrome" is in black, white or monochrome image or other condition.

7.2 NO Image after put on the power

- ① Check if signal cable connecting is in good condition.
- ② Check signal cable connecting, and make sure to use the standard adapter to connect the monitor. If power is supplied by battery, please check if the battery is fully charged.

7.3 Earphone No sound

- ① Check if Volume control do not open, press the volume button, and try to increase the volume.
- If there are still other problems, please contact with our related technologists.
- ★ As we are improving product features and product performance, so if there is any change on the specification without prior notice.