

FEELWORLD®

TP2

DSLR CAMERA VERSION

TP2A

SMARTPHONE+DSLR UNIVERSALVERSION



## PRODUCT INSTRUCTION

**Smartphone/Tablet/DSLR Teleprompter**

Patent product, Support wide angle lens

Patent No:202120181964.6




# Contents


- ◆ Packing list
- ◆ Structure
- ◆ Installation
- ◆ App Download
- ◆ App Instruction
- ◆ Remote Controller
- ◆ FAQ

# Packing List

## TP2 DSLR Camera Version Packing List



Teleprompter



Smartphone/Tablet clamp



Lens adapter  
(49/52/55/58/62/67/72/77mm)



Remote controller



Drawstring bag




Microfiber cloth




User Manual

# Packing List


## TP2A DSLR Camera + Smartphone Version Packing List



Teleprompter



Smartphone/Tablet clamp



Magnetic smartphone clamp



Lens adapter  
(49/52/55/58/62/67/72/77mm)



Foam ring



Remote controller



Drawstring bag




Microfiber cloth





User Manual

## Structure



## Structure



## Installation

### 1. Tablet /Smartphone Prompting, DSLR Camera Recording Supports below 8" for tablet



Take out the suitable lens adapter to install on your camera



Install the teleprompter on the camera



Install the phone/tablet clamp



Push the "PUSH" to lock the phone/tablet clamp



Put the tablet on the tablet clamp



Install the whole set on the tripod. The two cold shoe seat on the top of teleprompter can mount microphone,fill light, etc.



Turn on the camera and make sure full screen

## Installation

### 2. Tablet Prompting, Smartphone Recording



Choose a foam ring and put it into phone lens adapter



Make sure put it well




Install it on the back of the teleprompter



Take out magnetic phone clamp



Put it on the middle of the phone



Can be sucked on the right or left side small iron piece to meet horizontal shooting



Also can be sucked on the below small iron piece to meet vertical shooting



Intall the phone/tablet clamp on the teleprompter



Push the PUSH to lock it



Put the tablet on it



Install the whole set on the tripod. The two cold seats on the top teleprompter can mount microphone, fill light, etc.



Turn on the recording of the phone and make sure full screen

## APP Download

iOS APP Download



iOS user search “FEELWORLD”

Android APP Download



Android users search “FEELWORLD” in Google Play to install




or scan the QR code to download

## APP Instruction


After installed APP and enter app

Tap “+” to enter Edit dialogue




You can edit the title and content directly or click “Open” to import the text from the phone, then click “Save”

Click “whole”, you can manage the whole files




# APP Instruction

Click “Folder Management”, you can set new folder or delete folder




After saved the file, click the text to enter the play interface.

You can also tap icon to edit the text or tap icon to manage the file



If you want to delete the file, please swipe left at the corresponding file location and tap “Delete”



## APP Instruction

After enterd play interface and tap any position, the function menu will show on the bottom, tap again can hide the function menu.

Click on the desired function icon to turn on its function, and the icon display red. Tap again to turn off the function.



: Play/Pause



: Adjust the font size, word space, space, text color, background



: Adjust browse speed



: Loop play



: Vertical/Horizontal screen switch



: Mirror



TP10 is a folding and portable teleprompter which feature with 10-inch standard beam splitter allows you to clearly read scrolling text while looking directly into the camera, perfect for vlog, live broadcast, online class, video recording, interviews, video studio, news and presentation. No need to recite the script, confidence and charming! It can be prompted via smartphone or tablet while DSLR camera or phone is shooting. Supports wide angle lens, Android/iOS app, Bluetooth remote control, easy to operate, make the video production more efficient. Use with exquisite special storage case, more convenient to carry. It is ideal for video, program creator.



## Remote Controller

### Remote Button Instruction



Notice: Due to different brand phone, some smartphone function will be different after connected the remote.

## Remote Controller

### Remote Use Instruction

- 1.Power on: Keep press power button, until the lights on (about 2 seconds).
- 2.Power off: Keep press power button, until the lights off (about 5 seconds).

Notice: if power on without connect anything, it will power off after 5 minutes;  
if connected the phone, it will power off after 30 minutes.

### 3.iOS Connect

Turn on the Bluetooth of the phone first, then turn on APP, and power on the remote controller last. LED lights on, auto into pairing mode, allowing the Bluetooth pair. The APP will show automatically connected to FeelWorld-xx, and the connection is successful.

What can I do if my iPhone can not connect with remote controller?

- 1, pls go to bluetooth connection of your phone, check if remote controller had been connected by iphone;
- 2,then follow below steps to reconnect: 1) disconnect iphone Bluetooth , and switch off remote controller; 2) turn on iPhone bluetooth, open app, and then switch on remote controller.

### 4. Andriod Connect

After power on, LED light on, auto pairing mode, turn on the Bluetooth of the phone, then turn on APP, will show the Bluetooth connected automatically.



## FAQ



FAQ: The remote controller can not connect the Android phone, how can I do?

1. Please check Location Permission on your phone, the connection need turn on permission.
2. Please check if the remote controller has been connected with your phone.
3. Please check if there is Bluetooth signal from remote controller.(check by other app to detect the Bluetooth )
4. Reboot the remote controller, reopen the app.

FAQ: The remote controller has been connected my Android phone, but it can not control the app.

1. Please close other app at background on your phone.
2. Please turn off Bluetooth on other phones on worksite, to make sure your Android phone is the only device to connect the remote controller.
3. Please make sure that every time to connect with your phone is by app, not by Setting on you phone.

★ As we are improving product features and product performance, so if there is any change on the specification without prior notice.