

FEELWORLD®



TP10

10" Portable Teleprompter
PRODUCT INSTRUCTION

Contents

- Cautions
- Features
- Packing List
- Installation
- Remote Controller
- APP Download
- Structure
- Parameter
- FAQ

- Do not expose the device to water or leaking liquid
- Do not put the device near the fire source
- It is strictly forbidden to drop or collide. If the coated glass is damaged due to the drop or collision, please contact the after-sales service and change the glass in time. The corresponding cost shall be borne by the customer.
- Please do not disassemble the equipment without authorization. If the equipment cannot be used normally due to carelessly disassembly, please send it back to the company for re-commissioning. All the expenses incurred will be borne by the customer.

- Split foldable design, easier to carry
- Industry standard beam split glass with 70/30 visible light transmission
- Supports smartphone/tablet prompting, DSLR camera/smartphone vertical and horizontal shooting
- Supports up to 24mm wide angle lens, larger vision
- Multiple 1/4 universal screw holes can be quickly mounting microphones and other equipments
- Support Android/iOS APP, bluetooth remote control
- Portable carrying case, better protect the device and more convenient to move



Teleprompter



Remote Controller



Phone/Tablet Clamp



User Manual



Carrying Case



Quick Assembly Accessory



Phone Clamp



Foam Ring

OPTIONAL



Phone Clamp Accessory



Sun Hood



Microfiber Cloth



Support Rod



Clamp



Lens Adapter (49/52/55/58/62/67/72/77/82mm)



1/4 C-ring Screw



Mini Hot Shoe



1/4 to 1/4 Screw

Phone/Tablet Clamp Installation



① Lock phone/tablet clamp and quick assembly accessory together via a 1/4 C-ring screw



② After locking, install to the slot which under the glass and press PUSH lock



③ Install the sun hood on the teleprompter



④ Fixed phone or tablet (Pls press the arrow button up and stretch when placing the tablet)

Camera Shooting Installation



① For camera shooting, pls install a ring adapter of the corresponding size on the camera lens



② After installing, take into the ring which behind the teleprompter to fix it

Phone Shooting Installation



① For phone shooting , pls install 72mm ring adapter and foam ring



② After installing, take into the ring which behind the teleprompter to fix it



③ Lock phone clamp and phone clamp accessory together via a 1/4 C-ring screw



④ For horizontal shooting, pls slide into the left slot and reinforce it with a 1/4 C-ring screw



⑤ Fix the phone on the phone clamp and adjust the lens



⑥ For vertical shooting, pls slide into the right slot and reinforce it with a 1/4 C-ring screw



⑦ Fix the phone on the phone clamp and adjust the lens



⑧ Install the assembled kit on the tripod, the installation is completed



Notice: Due to different brand phone, some smartphone function will be different after connected the remote.

REMOTE USE INSTRUCTION

1. Power on

Keep press power button, until the lights on (about 2 seconds).

2. Power off

Keep press power button, until the lights off (about 5 seconds).

Notice: if power on without connect anything, it will power off after 5 minutes; if connected the phone, it will power off after 30 minutes.

3. iOS Connection

Turn on the Bluetooth of the phone first, then turn on APP, and power on the remote controller last. LED lights on, auto into paring mode, allowing the Bluetooth pair. The APP will show automatically connected to FEELWORLD-XX, and the connection is successful.

Notice: What can I do if my iPhone can not connect with remote controller?

1. pls go to bluetooth connection of your phone, check if remote controller had been connected by iphone;

2. then follow below steps to reconnect:

1) disconnect iphone Bluetooth , and switch off remote controller;

2) turn on iPhone Bluetooch, open app, and then switch on remote controller.

4. Android Connection

After power on, LED light on, auto into paring mode. Turn on the Bluetooth of the phone, then turn on APP, will show the Bluetooth connected automatically.

iOS APP Download



iOS user search "FEELWORLD" to download



Android APP Download



Android user search "FEELWORLD" in Google Play to download




or scan the QR code to download



APP INSTRUCTION

After installed APP and enter app

Tap “+” to enter Edit dialoge



Click “Folder Management”, you can set new folder or delete folder




You can edit the title and content directly or click “Open” to import the text from the phone, then click “Save”

Click “whole”, you can manage the whole files




After saved the file, click the text to enter the play interface.

You can also tap  icon to edit the text or tap  icon to manage the file



If you want to delete the file, please swipe left at the corresponding file location and tap “Delete”




After enterd play interface and tap any position, the function menu will show on the bottom, tap again can hide the function menu.

Click on the desired function icon to turn on its function, and the icon display red. Tap again to turn off the function.



 : Adjust the font size, word space, space, text color, background



TP10 is a folding and portable teleprompter which features with 10-inch standard beam splitter allows you to clearly read scrolling text while looking directly into the camera. Perfect for shooting, live broadcast, on-camera, video recording, interviews, video studios, news and presentation. No need to recite the script, confidence and charming! It can be prompted via smartphone or tablet while DSLR camera or phone is shooting. Supports wide angle lens, Android/iOS app, Bluetooth remote control, and more. Make the video production more efficient. Use with exquisite special storage case, more convenient to carry. It is ideal for video, program, tutorial.



Beamsplitter glass size	118x188mm
Main material	ABS
Transmission/ reflection ratio	70/30
Shooting focal length	More than 24mm
Compatible lens	49/52/55/58/62/67/72/77/82mm
Compatible phone	59-90mm
Compatible tablet	110-175mm
Unit size	216*180*27mm
Unit weight	315g

FAQ: The remote controller can not connect the Android phone, how can I do?

1. Please check Location Permission on your phone, the connection need turn on permission.
2. Please check if the remote controller has been connected with your phone.
3. Please check if there is Bluetooth signal from remote controller.(check by other app to detect the Bluetooth)
4. Reboot the remote controller, reopen the app.

FAQ: The remote controller has been connected my Android phone, but it can not control the app.

1. Please close other app at background on your phone.
2. Please turn off Bluetooth on other phones on worksite, to make sure your Android phone is the only device to connect the remote controller.
3. Please make sure that every time to connect with your phone is by app, not by Setting on you phone.